



NOTE:  
WHERE DRAIN LINE CROSSES PREVIOUSLY INSTALLED SANITARY SEWER,  
WATER OR GAS MAIN, ETC. TRENCH SHALL BE EXCAVATED DOWN TO  
THE PREVIOUSLY LAID CONDUIT AND BACKFILLED WITH COMPACTED #2  
CRUSHER RUN STONE TO INSURE ADEQUATE SUPPORT.

## DRAIN LINE BEDDING

NOT TO SCALE - REVISED: 06/12/23